

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**

FOLD

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**

FOLD

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**

FOLD

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**

FOLD

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**

FOLD

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**

FOLD

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**

FOLD

13071 **CAROUSEL FLOOR BOARDS** - 8.5"x 11" Format

- Print 8 times.
- Cut out the shapes and tape sides A & B together.
- Use a hole punch for the holes.

**SIDE A**

FOLD

FOLD

FOLD

**SIDE B**


FOLD

13071

**CAROUSEL FLOOR BOARDS**

11" x 17" Format

- Print 4 times.
- Use a hole punch for the holes.




13071

**CAROUSEL FLOOR BOARDS**

11" x 17" Format

- Print 4 times.
- Use a hole punch for the holes.




13071

**CAROUSEL FLOOR BOARDS**

11" x 17" Format

- Print 4 times.
- Use a hole punch for the holes.




13071

**CAROUSEL FLOOR BOARDS**

11" x 17" Format

- Print 4 times.
- Use a hole punch for the holes.



13071 **CAROUSEL** - Center Graphic - 8.5" x 11" Format - Side A (print 2 copies of each side - 4 total)



**SIDE A**

13071 **CAROUSEL** - Center Graphic - 8.5" x 11" Format - Side A (print 2 copies of each side - 4 total)



**SIDE A**

13071 **CAROUSEL** - Center Graphic - 8.5" x 11" Format - Side B (print 2 copies of each side - 4 total)



**SIDE B**

13071 **CAROUSEL** - Center Graphic - 8.5" x 11" Format - Side B (print 2 copies of each side - 4 total)



**SIDE B**

13071 **CAROUSEL** - Center Graphic - 11" x 17" Format - Print 2



13071 **CAROUSEL** - Center Graphic - 11" x 17" Format - Print 2

