







DOUBLE DIP ROLLER COASTER™



1 - 3




1 - 7







4 - 6

7


1 - 3









10






1 - 10




1 - 9



Did you install 2 AA (or LR6) batteries in the motor?








x8

1 - 13


14



1 - 14




x10




x1


1 - 14



15




1 - 15





x6




16




1 - 15




1 - 16










x2





23






x2







25



x2







Attaching Chain Links

IMPORTANT:

Attach all the chain links in the same direction.



32

x22



33

x2



34

32

32

32

32

32

32

32



32

32

32

32

32

33

35

32

32

32

32

32

32

32



32



32

32

32

32

33



37

36

